

CHIPSEC

version 1.2.5



Platform Security Assessment Framework

November 04, 2016



Contents

CHIPSEC	1
Description	1
Installation	1
Windows Installation	1
Linux Installation	3
Mac OS X Installation	4
UEFI Shell Installation	5
Using CHIPSEC	6
Command Line Usage	7
Using CHIPSEC as a Python Package	8
Compiling CHIPSEC Executables on Windows	8
Writing Your Own Modules (security modules)	8
CHIPSEC Components and Structure	9
Core components	10
Platform Configuration	11
OS/Environment Helpers	13
HW Abstraction Layer (HAL)	14
Utility command-line scripts	20
Auxiliary components	28
Executable build scripts	28
CHIPSEC Modules	28
Introduction	28
Modules Description	29



CHIPSEC

Welcome to the CHIPSEC documentation!

Questions about CHIPSEC can be directed to chipsec@intel.com

Warning

Chipsec should only be used on test systems!

It should not be installed/deployed on production end-user systems.

There are multiple reasons for that:

1. Chipsec kernel drivers provide direct access to hardware resources to user-mode applications (for example, access to physical memory). When installed on production systems this could allow malware to access privileged hardware resources.
2. The driver is distributed as source code. In order to load it on Operating System which requires kernel drivers to be signed (for example, 64 bit versions of Microsoft Windows 7 and higher), it is necessary to enable TestSigning (or equivalent) mode and sign the driver executable with test signature. Enabling TestSigning (or equivalent) mode turns off an important OS kernel protection and should not be done on production systems.
3. Due to the nature of access to hardware, if any chipsec module issues incorrect access to hardware resources, Operating System can hang or panic.

Description

CHIPSEC is a framework for analyzing the security of PC platforms including hardware, system firmware (BIOS/UEFI), and the configuration of platform components. It includes a security test suite, security assessment tools for various low level components/interfaces, and basic forensic capabilities for firmware.

CHIPSEC can run from Windows, Linux, Mac OS X and UEFI Shell.

Installation

CHIPSEC supports Windows, Linux, and UEFI shell. Circumstances surrounding the target platform may change which of these environments is most appropriate. When running CHIPSEC on client PC systems, Windows may be preferred. However, sometimes it may be preferable to assess platform security without interfering with the normal operating system. In these instances, CHIPSEC may be run from a bootable USB thumb drive - either a Live Linux image or a UEFI shell.

Windows Installation

CHIPSEC supports the following versions:

- Windows 7, 8, 8.1, 10 x86 and 64-bit
- Windows Server 2008, 2012, 2016 x86 and 64-bit

Please follow the steps below to install CHIPSEC framework on Windows:

1. Install [Python](#)



2. Install `pywin32` and `setuptools` packages:

```
pip install setuptools
```

```
pip install pywin32
```

To build chipsec executables, you may optionally want to install `py2exe`:

```
pip install py2exe
```

To get colored console output, you may optionally want to install `WConio`.

3. Build CHIPSEC kernel driver. Please follow the instructions in `\drivers\win7\readme`. Skip this step if you already have `chipsec_hlpr.sys` driver binary for your version of Windows

4. Copy CHIPSEC driver (`chipsec_hlpr.sys`) to proper directory `\chipsec\helper\win\win7_<arch>` where `<arch>` is "x86" or "amd64" (default path is `\chipsec\helper\win\win7_amd64`)

5. Install CHIPSEC framework

To automatically install from PyPI:

```
pip install chipsec
```

To manually install CHIPSEC as a package:

```
git clone https://github.com/chipsec/chipsec
```

```
python setup.py install
```

Note

When installing CHIPSEC on Windows, the driver isn't built automatically (as when installing on Linux). You'll need to build Windows driver and copy it to proper directory (see steps 3 and 4) prior to installing CHIPSEC

6. Turn off kernel driver signature checks

Windows 10 64-bit / Windows 8, 8.1 64-bit (with Secure Boot enabled) / Windows Server 2016 64-bit / Windows Server 2012 64-bit (with Secure Boot enabled):

- In CMD.EXE: `shutdown /r /t 0 /o`
- Navigate: Troubleshooting > Advanced Settings > Startup Options > Reboot
- After reset choose `F7` "Disable driver signature checks"

Alternatively, disable Secure Boot in the BIOS setup screen then disable driver signature checks as with Secure Boot disabled

Windows 7 64-bit / Windows Server 2008 64-bit / Windows 8 (with Secure Boot disabled) / Windows Server 2012 (with Secure Boot disabled):

Boot in Test mode (allows self-signed certificates)

- Start CMD.EXE as Administrator
- `BcdEdit /set TESTSIGNING ON`
- Reboot

If that doesn't work, run these additional commands:

```
BcdEdit /set noIntegrityChecks ON
```

```
BcdEdit /set loadoptions DISABLE_INTEGRITY_CHECKS
```

Alternatively, press `F8` when booting Windows and choose "No driver signatures enforcement" option to turn off driver signature checks



7. Run CHIPSEC

- Launch CMD.EXE as Administrator
- You can use commands below to run CHIPSEC. CHIPSEC will automatically load the driver and unload it when done.

```
python chipsec_main.py
```

```
python chipsec_util.py
```

- If CHIPSEC is used as a standalone tool, run above commands from where CHIPSEC is.

Note

You can manually register and start CHIPSEC service/driver. CHIPSEC will attempt to connect to already running chipsec service.

To create and start chipsec service (in CMD.EXE)

```
sc create chipsec binpath=<path_to_sys> type=kernel DisplayName="Chipsec driver"
```

```
sc start chipsec
```

Then to stop and delete chipsec service:

```
sc stop chipsec
```

```
sc delete chipsec
```

Linux Installation

Tested on:

- Fedora LXDE 64bit
- Ubuntu 64bit
- Debian 64bit and 32bit
- Linux UEFI Validation (LUV)

Installing CHIPSEC

Installing necessary packages

You will need to install or update the following dependencies before installing CHIPSEC:

```
# yum install kernel kernel-devel-$(uname -r) python python-devel gcc nasm
```

or

```
# apt-get install build-essential python-dev python gcc \  
linux-headers-$(uname -r) nasm
```

You can use CHIPSEC on a desired Linux distribution or create a live Linux image on a USB flash drive and boot to it. For example, you can use [liveusb-creator](#) to create live Fedora image on a USB drive

You will also need to install `setuptools` package:

```
pip install setuptools
```

Installing from PyPI



1. Installing CHIPSEC from PyPI will automatically build all necessary components including kernel module and install CHIPSEC as a package. CHIPSEC will automatically load the kernel module and unload it when done.

```
# pip install chipsec
```

2. Now you can use these commands from any directory to run CHIPSEC:

```
# sudo chipsec_main
# sudo chipsec_util
# sudo python -m chipsec_main
# sudo python -m chipsec_util
```

Installing Manually

Clone chipsec Git repository and install it as a package:

```
# git clone https://github.com/chipsec/chipsec
# python setup.py install
# sudo chipsec_main
```

To use CHIPSEC *in place* without installing it:

```
# python setup.py build_ext -i
# sudo python chipsec_main.py
```

Note

To use CHIPSEC without installing it using `setup.py`, just build kernel module and helper components in place:

```
# make -C ../drivers/linux
# cp ../drivers/linux/chipsec.ko ../chipsec/helper/linux/
# make -C ../chipsec/helper/linux/
```

Mac OS X Installation

Warning

Mac OS X support is currently in Alpha release

Please follow the steps below to install CHIPSEC on Mac OS X.

Installing Manually

1. Build CHIPSEC kernel module. Please follow the instructions in `drivers/osx/README`
2. Turn the System Integrity Protection off. Refer to [Configuring System Integrity Protection](#)
3. Reboot and load the CHIPSEC driver

```
# kextutil chipsec.kext
```

Running CHIPSEC

Within the root CHIPSEC directory, run:

```
# python chipsec_main.py
```



```
# python chipsec_util.py
```

When done, unload the driver and re-enable the System Integrity Protection

```
# kextunload -b com.google.chipsec
```

UEFI Shell Installation

Installing CHIPSEC for UEFI Shell

1. Extract contents of `__install__/UEFI/chipsec_uefi_<arch>.zip` to the EFI drive which can be either USB flash drive (e.g. DUET USB drive) or HDD/SSD hard drive (e.g. EFI System Partition). `<arch>` should correspond to your UEFI shell and can be `x64`, `ia32` or `i586`. This will create `/efi/Tools` directory with `Python.efi` and `/efi/StdLib` with subdirectories
2. Copy contents of CHIPSEC anywhere on the EFI drive (for example, to `chipsec` directory in root). The contents of your drive should look like follows:

```
\
  efi\
    boot\
      bootx64.efi
    StdLib\
      lib\
        python.27\
          [lots of python files and directories]
    Tools\
      Python.efi
  chipsec\
    chipsec\
    chipsec_main.py
    chipsec_util.py
    ...
```

Note

The EFI drive should already include a UEFI Shell binary in `/efi/boot`. On 64-bit platforms the shell will likely be named `bootx64.efi`

3. Run your UEFI shell

- If UEFI shell is on the USB removable drive, you'll need to boot off of the USB drive (rebooting will load UEFI shell).
- If your UEFI firmware allows booting from any file, choose to boot from your UEFI shell binary from the UEFI firmware setup options
- Some systems have embedded UEFI shell which can be booted from setup options

4. Run CHIPSEC in UEFI shell

```
1. fs0:
```

```
2. python chipsec_main.py or python chipsec_util.py
```



(OPTIONAL) Extending CHIPSEC functionality for UEFI

Skip this section if you don't plan on extending native UEFI functionality for CHIPSEC.

Native functions accessing HW resources are built directly into Python UEFI port in built-in `edk2` module. If you want to add more native functionality to Python UEFI port for `chipsec`, you'll need to re-build Python for UEFI:

1. Check out [AppPkg with Python 2.7.2](#) port for UEFI from SVN
 - You'll also need to check out `StdLib` and `StdLibPrivateInternalFiles` packages from SVN
 - Alternatively download latest EADK ([EDK II Application Development Kit](#)). EADK includes `AppPkg/StdLib/StdLibPrivateInternalFiles`. Unfortunately, EADK Alpha 2 doesn't have Python 2.7.2 port so you'll need to check it out SVN.
2. Add functionality to Python port for UEFI
 - Python 2.7.2 port for UEFI is in `<UDK>\AppPkg\Applications\Python`
 - All `chipsec` related functions are in `<UDK>\AppPkg\Applications\Python\Efi\edk2module.c` (`#ifdef CHIPSEC`)
 - `Asm` functions are in `<UDK>\AppPkg\Applications\Python\Efi\cpu.asm` e.g. `<UDK>` is `C:\UDK2010.SR1`
 - Add `cpu.asm` under the `Efi` section in `PythonCore.inf`
3. Build `<UDK>/AppPkg` with Python
 - Read instructions in `<UDK>\AppPkg\ReadMe.txt` and `<UDK>\AppPkg\Applications\Python\PythonReadMe.txt`
 - Binaries of `AppPkg` and `Python` will be in `<UDK>\Build\AppPkg\DEBUG_MYTOOLS\X64\`
4. Create directories and copy Python files on DUET USB drive
 - Read instructions in `<UDK>\AppPkg\Applications\Python\PythonReadMe.txt`

(OPTIONAL) Building bootable USB thumb drive with UEFI Shell

You can build bootable USB drive with UEFI shell using EDK DUET environment:

1. [Download UDK from Tianocore](#) (Tested with `UDK2010.SR1`)
2. Follow instructions in `DuetPkg/ReadMe.txt` to create a bootable USB thumb drive with UEFI Shell (DUET)

Using CHIPSEC

CHIPSEC should be launched as Administrator/root.

- In command shell, run


```
# python chipsec_main.py
# python chipsec_util.py
```
- For help, run


```
# python chipsec_main.py --help
# python chipsec_util.py help
```



Command Line Usage

• Command Line Usage

```
# chipsec_main.py [options]
```

Options

-m --module	specify module to run (example: -m common.bios_wp)
-a --module_args	additional module arguments, format is 'arg0,arg1..'
-v --verbose	verbose mode
-d --debug	show debug output
-l --log	output to log file

Advanced Options

-p --platform	explicitly specify platform code. Should be among the supported platforms: [SNB IVB KBL JKT BYT QRK BDW IVT AVN CHT HSW SKL HSX]
-n --no_driver	chipsec won't need kernel mode functions so don't load chipsec driver
-i --ignore_platform	run chipsec even if the platform is not recognized
-x --xml	specify filename for xml output (JUnit style).
-t --moduletype	run tests of a specific type (tag).
--list_tags	list all the available options for -t,--moduletype
-I --include	specify additional path to load modules from
--failfast	fail on any exception and exit (don't mask exceptions)
--no_time	don't log timestamps

Exit Code

CHIPSEC returns an integer exit code:

- Exit code is 0: all modules ran successfully and passed
- Exit code is not 0: each bit means the following:
 - Bit 0: SKIPPED at least one module was skipped
 - Bit 1: WARNING at least one module had a warning
 - Bit 2: DEPRECATED at least one module uses deprecated API
 - Bit 3: FAIL at least one module failed
 - Bit 4: ERROR at least one module wasn't able to run
 - Bit 5: EXCEPTION at least one module thrown an unexpected exception



Using CHIPSEC as a Python Package

CHIPSEC will automatically attempt to create and start its service, including load its kernel-mode driver. If chipsec service is already running then it will attempt to connect to the existing service.

Use `--no-driver` command-line option if you want CHIPSEC to use native OS API rather than own kernel module. This option can also be used if loading kernel module is not needed to use desired functionality.

Use `-m --module` to run a specific module (e.g. security check, a tool or a PoC..):

- `# python chipsec_main.py -m common.bios_wp`
- `# python chipsec_main.py -m common.spi_lock`
- `# python chipsec_main.py -m common.smrr`
- You can also use CHIPSEC to access various hardware resources:
`# python chipsec_util.py`

Using CHIPSEC as a Python Package

Install CHIPSEC manually or from PyPI as described in the Installation section.

You can then use CHIPSEC from your Python project or from the Python shell:

```
>>> import chipsec_main
>>> chipsec_main.main()
>>> chipsec_main.main(['-m', 'common.bios_wp'])
```

```
>>> import chipsec_util
>>> chipsec_util.main()
>>> chipsec_util.main(['spi', 'info'])
```

Compiling CHIPSEC Executables on Windows

Directories `bin/<arch>` (where `<arch>` is `x86` or `amd64`) should already contain compiled CHIPSEC binaries: `chipsec_main.exe`, `chipsec_util.exe`

- To run all security tests run `chipsec_main.exe` from `bin` directory:

```
# chipsec_main.exe
```

- To access hardware resources run `chipsec_util.exe` from `bin` directory:

```
# chipsec_util.exe
```

If directory `bin` doesn't exist, then you can compile CHIPSEC executables:

- Install `py2exe` package from <http://www.py2exe.org>
- From the `scripts` directory run `build_exe_<arch>.py` as follows:

```
# python build_exe_<arch>.py py2exe
```

- `chipsec_main.exe`, `chipsec_util.exe` executables and required libraries will be created in `bin/<arch>` directory

Writing Your Own Modules (security modules)

Your module class should subclass `BaseModule` and implement at least the methods named `is_supported` and `run`. When `chipsec_main` runs, it will first run `is_supported` and if that returns `true`, then it will call `run`.



As of CHIPSEC version 1.2.0, CHIPSEC implements an abstract name for platform *controls*. Module authors are encouraged to create controls in the XML configuration files for important platform configuration information and then use `get_control` and `set_control` within modules. This abstraction allows modules to test for the abstract control without knowing which register provides it. (This is especially important for test reuse across platform generations.)

Most modules read some platform configuration and then pass or fail based on the result. For example:

1. Define the control in the platform XML file (in `chispec/cfg`):

```
<control name="BiosLockEnable" register="BC" field="BLE" desc="BIOS Lock Enable"/>
```

2. Get the current status of the control:

```
ble = chipsec.chipset.get_control( self.cs, 'BiosLockEnable' )
```

3. React based on the status of the control:

```
if ble: self.logger.log_passed_check("BIOS Lock is set.")
else: self.logger.log_failed_check("BIOS Lock is not set.")
```

4. Return:

```
if ble: return ModuleResult.PASSED
else: return ModuleResult.FAILED
```

When a module calls `get_control` or `set_control`, CHIPSEC will look up the control in the platform XML file, look up the corresponding register/field, and call `chipsec.chipset.read_register_field` or `chipsec.chipset.write_register_field`. This allows modules to be written for abstract *controls* that could be in different registers on different platforms.

The CHIPSEC HAL and other APIs are also available within these modules. See the next sections for details about the available functionality.


Copy your module into the `chipsec/modules/` directory structure

- Modules specific to a certain platform should implement `is_supported` function which returns `True` for the platforms the module is applicable to
- Modules specific to a certain platform can also be located in `chipsec/modules/<platform_code>` directory, for example `chipsec/modules/hsw`. Supported platforms and their code can be found by running `chipsec_main.py --help`
- Modules common to all platform which CHIPSEC supports can be located in `chipsec/modules/common` directory

If a new platform needs to be added:

- Modify `chipsec/chipset.py` to include the Device ID for the platform you are adding
- Review the platform datasheet and include appropriate information in an XML configuration file for the platform. Place this file in `chipsec/cfg`. Registers that are correctly defined in `common.xml` will be inherited and do not need to be added. Use `common.xml` as an example. It is based on the 4th Generation Intel Core platform (Haswell).

CHIPSEC Components and Structure



Core components

<code>chipsec_main.py</code>	main application logic and automation functions
<code>chipsec_util.py</code>	utility functions (access to various hardware resources)
<code>chipsec/chipset.py</code>	chipset detection
<code>chipsec/command.py</code>	base class for util commands
<code>chipsec/defines.py</code>	common defines
<code>chipsec/file.py</code>	reading from/writing to files
<code>chipsec/logger.py</code>	logging functions
<code>chipsec/module.py</code>	generic functions to import and load modules
<code>chipsec/module_common.py</code>	base class for modules
<code>chipsec/xmlout.py</code>	support for JUnit compatible XML output (-x command-line option)
<code>chipsec/helper/helpers.py</code>	registry of supported OS helpers
<code>chipsec/helper/oshelper.py</code>	OS helper: wrapper around platform specific code that invokes kernel driver



Platform Configuration

chipsec/cfg/	platform specific configuration xml files
chipsec/cfg/common.xml	common configuration
chipsec/cfg/<platform>.xml	configuration for a specific <platform>

chipsec.cfg.avn.xml

XML configuration for Avoton based platforms

- Intel(R) Atom(TM) Processor C2000 Product Family for Microserver, September 2014
<http://www.intel.com/content/www/us/en/processors/atom/atom-c2000-microserver-datasheet.html>

chipsec.cfg.bdw.xml

XML configuration for Broadwell based platforms

chipsec.cfg.bytr.xml

XML configuration for Bay Trail based platforms

- Intel(R) Atom(TM) Processor E3800 Product Family Datasheet, May 2016, Revision 4.0
<http://www.intel.com/content/www/us/en/embedded/products/bay-trail/atom-e3800-family-datasheet.html>

chipsec.cfg.chipsec_cfg.xsd

XML Schema for platform configuration XML files

chipsec.cfg.cht.xml

XML configuration for Cherry Trail and Braswell SoCs

- Intel(R) Atom(TM) Processor Z8000 series datasheet
<http://www.intel.com/content/www/us/en/processors/atom/atom-z8000-datasheet-vol-2.html>
- N-series Intel(R) Pentium(R) and Celeron(R) Processors Datasheet
<http://www.intel.com/content/dam/www/public/us/en/documents/datasheets/pentium-celeron-n-series-datasheet-vol-2.pdf>

chipsec.cfg.common.xml

Common (default) XML platform configuration file



chipsec.cfg.hsw.xml

XML configuration file for Haswell based platforms

chipsec.cfg.hsx.xml

XML configuration file for Haswell Server based platforms

chipsec.cfg.iommu.xml

XML configuration file for Intel Virtualization Technology for Directed I/O (VT-d)

- Section 10 of Intel Virtualization Technology for Directed I/O
<http://www.intel.com/content/dam/www/public/us/en/documents/product-specifications/vt-directed-io-spec.pdf>

chipsec.cfg.ivt.xml

XML configuration file for Ivytown (Ivy Bridge-E) based platforms

chipsec.cfg.jkt.xml

XML configuration file for Jaketown (Sandy Bridge-E) based platforms

chipsec.cfg.kbl.xml

XML configuration file for Kaby Lake based platforms

- 7th Generation Intel(R) Processor Families for U/Y-Platforms
- 7th Generation Intel(R) Processor Families I/O for U/Y-Platforms
- <http://www.intel.com/content/www/us/en/processors/core/core-technical-resources.html>

chipsec.cfg.qrk.xml

XML configuration for Quark based platforms

chipsec.cfg.skl.xml

XML configuration file for Skylake based platforms

- 6th Generation Intel(R) Processor Datasheet for U/Y-Platforms



- 6th Generation Intel(R) Processor I/O Datasheet for U/Y-Platforms
- 6th Generation Intel(R) Processor Datasheet for S-Platforms
- 6th Generation Intel(R) Processor Datasheet for H-Platforms
- Intel(R) 100 Series Chipset Family Platform Controller Hub (PCH)
- <http://www.intel.com/content/www/us/en/processors/core/core-technical-resources.html>

chipsec.cfg.template.xml

Template for XML configuration file

OS/Environment Helpers

chipsec.helper.efi.efihelper module

On UEFI use the efi package functions

chipsec.helper.linux.helper module

Linux helper

chipsec.helper.osx.helper module

OSX helper

chipsec.helper.win.win32helper module

Management and communication with Windows kernel mode driver which provides access to hardware resources

Note

On Windows you need to install pywin32 Python extension corresponding to your Python version:
<http://sourceforge.net/projects/pywin32/>

chipsec.helper.helpers module



chipsec.helper.oshelper module

Abstracts support for various OS/environments, wrapper around platform specific code that invokes kernel driver

HW Abstraction Layer (HAL)

Components responsible for access to hardware (Hardware Abstraction Layer)

chipsec.hal.acpi module

HAL component providing access to and decoding of ACPI tables

chipsec.hal.acpi_tables module

HAL component decoding various ACPI tables

chipsec.hal.cmos module

CMOS memory specific functions (dump, read/write)

usage:

```
>>> cmos.dump_low()  
>>> cmos.dump_high()  
>>> cmos.dump()  
>>> cmos.read_cmos_low( offset )  
>>> cmos.write_cmos_low( offset, value )  
>>> cmos.read_cmos_high( offset )  
>>> cmos.write_cmos_high( offset, value )
```

chipsec.hal.cpu module

CPU related functionality

chipsec.hal.cpuuid module

CPUID information

usage:

```
>>> cpuuid(0)
```

chipsec.hal.ec module

Access to Embedded Controller (EC)

Usage:



```
>>> write_command( command )
>>> write_data( data )
>>> read_data()
>>> read_memory( offset )
>>> write_memory( offset, data )
>>> read_memory_extended( word_offset )
>>> write_memory_extended( word_offset, data )
>>> read_range( start_offset, size )
>>> write_range( start_offset, buffer )
```

chipsec.hal.hal_base module

Base for HAL Components

chipsec.hal.interrupts module

Functionality encapsulating interrupt generation CPU Interrupts specific functions (SMI, NMI)

usage:

```
>>> send_SMI_APMC( 0xDE )
>>> send_NMI()
```

chipsec.hal.io module

Access to Port I/O

usage:

```
>>> read_port_byte( 0x61 )
>>> read_port_word( 0x61 )
>>> read_port_dword( 0x61 )
>>> write_port_byte( 0x71, 0 )
>>> write_port_word( 0x71, 0 )
>>> write_port_dword( 0x71, 0 )
```

chipsec.hal.io_bar module

I/O BAR access (dump, read/write)

usage:

```
>>> get_IO_BAR_base_address( bar_name )
>>> read_IO_BAR_reg( bar_name, offset, size )
>>> write_IO_BAR_reg( bar_name, offset, size, value )
>>> dump_IO_BAR( bar_name )
```

chipsec.hal.iommu module

Access to IOMMU engines



chipsec.hal.mmio module

Access to MMIO (Memory Mapped IO) BARs and Memory-Mapped PCI Configuration Space (MMCFG)

usage:

```
>>> read_MMIO_reg(cs, bar_base, 0x0, 4 )
>>> write_MMIO_reg(cs, bar_base, 0x0, 0xFFFFFFFF, 4 )
>>> read_MMIO( cs, bar_base, 0x1000 )
>>> dump_MMIO( cs, bar_base, 0x1000 )
```

Access MMIO by BAR name:

```
>>> read_MMIO_BAR_reg( cs, 'MCHBAR', 0x0, 4 )
>>> write_MMIO_BAR_reg( cs, 'MCHBAR', 0x0, 0xFFFFFFFF, 4 )
>>> get_MMIO_BAR_base_address( cs, 'MCHBAR' )
>>> is_MMIO_BAR_enabled( cs, 'MCHBAR' )
>>> is_MMIO_BAR_programmed( cs, 'MCHBAR' )
>>> dump_MMIO_BAR( cs, 'MCHBAR' )
>>> list_MMIO_BARs( cs )
```

Access Memory Mapped Config Space:

```
>>> get_MMCFG_base_address(cs)
>>> read_mmcfg_reg( cs, 0, 0, 0, 0x10, 4 )
>>> read_mmcfg_reg( cs, 0, 0, 0, 0x10, 4, 0xFFFFFFFF )
```

DEPRECATED: Access MMIO by BAR id:

```
>>> read_MMIOBAR_reg( cs, mmio.MMIO_BAR_MCHBAR, 0x0 )
>>> write_MMIOBAR_reg( cs, mmio.MMIO_BAR_MCHBAR, 0xFFFFFFFF )
>>> get_MMIO_base_address( cs, mmio.MMIO_BAR_MCHBAR )
```

chipsec.hal.msgbus module

Access to message bus (IOSF sideband) interface registers on Intel SoCs

References: - Intel(R) Atom(TM) Processor E3800 Product Family Datasheet, May 2016, Revision 4.0

<http://www.intel.com/content/www/us/en/embedded/products/bay-trail/atom-e3800-family-datasheet.html>
(sections 3.6 and 13.4.6 - 13.4.8)

- Intel(R) Atom(TM) Processor D2000 and N2000 Series Datasheet, Volume 2, July 2012, Revision 003
<http://www.intel.com/content/dam/doc/datasheet/atom-d2000-n2000-vol-2-datasheet.pdf> (section 1.10.2)

usage:

```
>>> msgbus_reg_read( port, register )
>>> msgbus_reg_write( port, register, data )
```

```
>>> msgbus_read_message( port, register, opcode )
>>> msgbus_write_message( port, register, opcode, data )
>>> msgbus_send_message( port, register, opcode, data )
```

chipsec.hal.msr module

Access to CPU resources (for each CPU thread): Model Specific Registers (MSR), IDT/GDT

usage:

```
>>> read_msr( 0x8B )
>>> write_msr( 0x79, 0x12345678 )
>>> get_IDTR( 0 )
>>> get_GDTR( 0 )
```



```
>>> dump_Descriptor_Table( 0, DESCRIPTOR_TABLE_CODE_IDTR )
>>> IDT( 0 )
>>> GDT( 0 )
>>> IDT_all()
>>> GDT_all()
```

chipsec.hal.paging module

chipsec.hal.pci module

Access to of PCI/PCIe device hierarchy - enumerating PCI/PCIe devices - read/write access to PCI configuration headers/registers - enumerating PCI expansion (option) ROMs - identifying PCI/PCIe devices MMIO and I/O ranges (BARs)

usage:

```
>>> self.cs.pci.read_byte( 0, 0, 0, 0x88 )
>>> self.cs.pci.write_byte( 0, 0, 0, 0x88, 0x1A )
>>> self.cs.pci.enumerate_devices()
>>> self.cs.pci.enumerate_xroms()
>>> self.cs.pci.find_XROM( 2, 0, 0, True, True, 0xFED00000 )
>>> self.cs.pci.get_device_bars( 2, 0, 0 )
>>> self.cs.pci.get_DIDVID( 2, 0, 0 )
>>> self.cs.pci.is_enabled( 2, 0, 0 )
```

chipsec.hal.pcidb module

Note

THIS FILE WAS GENERATED

Auto generated from:

<http://www.pcidatabase.com/vendors.php?sort=id> <http://www.pcidatabase.com/reports.php?type=csv>

chipsec.hal.physmem module

Access to physical memory

usage:

```
>>> read_physical_mem( 0xf0000, 0x100 )
>>> write_physical_mem( 0xf0000, 0x100, buffer )
>>> write_physical_mem_dowrd( 0xf0000, 0xdeadbeef )
>>> read_physical_mem_dowrd( 0xfed40000 )
```

chipsec.hal.smbus module

Access to SMBus Controller



chipsec.hal.spd module

Access to Memory (DRAM) Serial Presence Detect (SPD) EEPROM

References:

http://www.jedec.org/sites/default/files/docs/4_01_02R19.pdf
http://www.jedec.org/sites/default/files/docs/4_01_02_10R17.pdf
http://www.jedec.org/sites/default/files/docs/4_01_02_11R24.pdf
http://www.jedec.org/sites/default/files/docs/4_01_02_12R23A.pdf
<http://www.simmtester.com/page/news/showpubnews.asp?num=184>
<http://www.simmtester.com/page/news/showpubnews.asp?num=153>
<http://www.simmtester.com/page/news/showpubnews.asp?num=101>
http://en.wikipedia.org/wiki/Serial_presence_detect

chipsec.hal.spi module

Access to SPI Flash parts

usage:

```
>>> read_spi( spi_flg, length )
>>> write_spi( spi_flg, buf )
>>> erase_spi_block( spi_flg )
```

Note

!! IMPORTANT: Size of the data chunk used in SPI read cycle (in bytes) default = maximum 64 bytes (remainder is read in 4 byte chunks)

If you want to change logic to read SPI Flash in 4 byte chunks: SPI_READ_WRITE_MAX_DBC = 4

@TBD: SPI write cycles operate on 4 byte chunks (not optimized yet)

Approximate performance (on 2-core SMT Intel Core i5-4300U (Haswell) CPU 1.9GHz): SPI read: ~7 sec per 1MB (with DBC=64)

chipsec.hal.spi_descriptor module

SPI Flash Descriptor binary parsing functionality

usage:

```
>>> fd = read_file( fd_file )
>>> parse_spi_flash_descriptor( fd )
```

chipsec.hal.spi_uefi module

SPI UEFI Region parsing

usage:

```
>>> parse_uefi_region_from_file( filename )
```



chipsec.hal.tpm module

Trusted Platform Module (TPM) HAL component

<https://trustedcomputinggroup.org>

chipsec.hal.tpm12_commands module

Definition for TPMv1.2 commands to use with TPM HAL

TCG PC Client TPM Specification TCG TPM v1.2 Specification

continueselftest (command_argv)

TPM_ContinueSelfTest informs the TPM that it should complete self-test of all TPM functions. The TPM may return success immediately and then perform the self-test, or it may perform the self-test and then return success or failure.

getcap (command_argv)

Returns current information regarding the TPM CapArea - Capabilities Area SubCapSize - Size of SubCapabilities SubCap - Subcapabilities

nvread (command_argv)

Read a value from the NV store Index, Offset, Size

pcrread (command_argv)

The TPM_PCRRead operation provides non-cryptographic reporting of the contents of a named PCR

startup (command_argv)

Execute a tpm_startup command. TPM_Startup is always preceded by TPM_Init, which is the physical indication (a system wide reset) that TPM initialization is necessary Type of Startup to be used: 1: TPM_ST_CLEAR 2: TPM_ST_STATE 3: TPM_ST_DEACTIVATED

chipsec.hal.ucode module

Microcode update specific functionality (for each CPU thread)

usage:

```
>>> ucode_update_id( 0 )
>>> load_ucode_update( 0, ucode_buf )
>>> update_ucode_all_cpus( 'ucode.pdb' )
>>> dump_ucode_update_header( 'ucode.pdb' )
```

chipsec.hal.uefi module

Main UEFI component using platform specific and common UEFI functionality

chipsec.hal.uefi_common module

Common UEFI/EFI functionality including UEFI variables, Firmware Volumes, Secure Boot variables, S3 boot-script, UEFI tables, etc.



chipsec.hal.uefi_platform module

Platform specific UEFI functionality (parsing platform specific EFI NVRAM, capsules, etc.)

```
UEFI_VARIABLE_STORE_HEADER_SIZE = 28
EFI_VARIABLE_HEADER_AUTH = "<HBB128sIIHH8s" EFI_VARIABLE_HEADER_AUTH_SIZE =
struct.calcsize(EFI_VARIABLE_HEADER_AUTH)
EFI_VARIABLE_HEADER = "<HBBIIHH8s" EFI_VARIABLE_HEADER_SIZE =
struct.calcsize(EFI_VARIABLE_HEADER)
```

chipsec.hal.vmm module

VMM specific functionality 1. Hypervisor hypercall interfaces 2. Second-level Address Translation (SLAT) 3. VirtIO devices 4. ...

Utility command-line scripts

CHIPSEC utilities provide the capability for manual testing and direct hardware access.

Warning

DIRECT HARDWARE ACCESS PROVIDED BY THESE UTILITIES COULD MAKE YOUR SYSTEM UNBOOTABLE. MAKE SURE YOU KNOW WHAT YOU ARE DOING!

Note

All numeric values in the instructions are in hex.

chipsec.utilcmd.acpi_cmd module

Command-line utility providing access to ACPI tables

```
class ACPICommand (argv, cs=None)
```

```
Bases: chipsec.command.BaseCommand
```

```
>>> chipsec_util acpi list
>>> chipsec_util acpi table <name>|<file_path>
```

Examples:

```
>>> chipsec_util acpi list
>>> chipsec_util acpi table XSDT
>>> chipsec_util acpi table acpi_table.bin
```

chipsec.utilcmd.chipset_cmd module

usage as a standalone utility:



```
>>> chipsec_util platform
```

```
class PlatformCommand (argv, cs=None)
  Bases: chipsec.command.BaseCommand
  chipsec_util platform
```

chipsec.utilcmd_cmos_cmd module

```
class CMOSCommand (argv, cs=None)
  Bases: chipsec.command.BaseCommand
```

```
>>> chipsec_util cmos dump
>>> chipsec_util cmos readl|writel|readh|writeh <byte_offset> [byte_val]
```

Examples:

```
>>> chipsec_util cmos dump
>>> chipsec_util cmos rl 0x0
>>> chipsec_util cmos wh 0x0 0xCC
```

chipsec.utilcmd_cpu_cmd module

```
class CPUCommand (argv, cs=None)
  Bases: chipsec.command.BaseCommand
```

```
>>> chipsec_util cpu info
>>> chipsec_util cpu cr <cpu_id> <cr_number> [value]
>>> chipsec_util cpu cpuid <eax> [ecx]
>>> chipsec_util cpu pt [paging_base_cr3]
```

Examples:

```
>>> chipsec_util cpu info
>>> chipsec_util cpu cr 0 0
>>> chipsec_util cpu cr 0 4 0x0
>>> chipsec_util cpu cpuid 40000000
>>> chipsec_util cpu pt
```

chipsec.utilcmd_decode_cmd module

CHIPSEC can parse an image file containing data from the SPI flash (such as the result of `chipsec_util spi dump`). This can be critical in forensic analysis.

Examples:

```
chipsec_util decode spi.bin vss
```

This will create multiple log files, binaries, and directories that correspond to the sections, firmware volumes, files, variables, etc. stored in the SPI flash.

```
class DecodeCommand (argv, cs=None)
  Bases: chipsec.command.BaseCommand
```

```
>>> chipsec_util decode <rom> [fw_type]
```

For a list of fw types run:

```
>>> chipsec_util decode types
```



Examples:

```
>>> chipsec_util decode spi.bin vss
```

chipsec.utilcmd.desc_cmd module

The `idt` and `gdt` commands print the IDT and GDT, respectively.

class GDTCommand (argv, cs=None)

Bases: **chipsec.command.BaseCommand**

```
>>> chipsec_util idt|gdt|ldt [cpu_id]
```

Examples:

```
>>> chipsec_util idt 0
>>> chipsec_util gdt
```

class IDTCommand (argv, cs=None)

Bases: **chipsec.command.BaseCommand**

```
>>> chipsec_util idt|gdt|ldt [cpu_id]
```

Examples:

```
>>> chipsec_util idt 0
>>> chipsec_util gdt
```

class LDTCommand (argv, cs=None)

Bases: **chipsec.command.BaseCommand**

```
>>> chipsec_util idt|gdt|ldt [cpu_id]
```

Examples:

```
>>> chipsec_util idt 0
>>> chipsec_util gdt
```

chipsec.utilcmd.ec_cmd module

class ECCommand (argv, cs=None)

Bases: **chipsec.command.BaseCommand**

```
>>> chipsec_util ec dump      [<size>]
>>> chipsec_util ec command  <command>
>>> chipsec_util ec read     <start_offset> [<size>]
>>> chipsec_util ec write    <offset> <byte_val>
>>> chipsec_util ec index    [<offset>]
```

Examples:

```
>>> chipsec_util ec dump
>>> chipsec_util ec command 0x001
>>> chipsec_util ec read    0x2F
>>> chipsec_util ec write   0x2F 0x00
>>> chipsec_util ec index
```

chipsec.utilcmd.interrupts_cmd module



Utility command-line scripts

```
class NMICommand (argv, cs=None)
```

```
Bases: chipsec.command.BaseCommand
```

```
>>> chipsec_util nmi
```

Examples:

```
>>> chipsec_util nmi
```

```
class SMICommand (argv, cs=None)
```

```
Bases: chipsec.command.BaseCommand
```

```
>>> chipsec_util smi <thread_id> <SMI_code> <SMI_data> [RAX] [RBX] [RCX] [RDX] [RSI] [RDI]
```

Examples:

```
>>> chipsec_util smi 0x0 0xDE 0x0  
>>> chipsec_util smi 0x0 0xDE 0x0 0xAAAAAAAAAAAAAAAA ..
```

chipsec.utilcmd.io_cmd module

The io command allows direct access to read and write I/O port space.

```
class PortIOCommand (argv, cs=None)
```

```
Bases: chipsec.command.BaseCommand
```

```
>>> chipsec_util io list  
>>> chipsec_util io <io_port> <width> [value]
```

Examples:

```
>>> chipsec_util io list  
>>> chipsec_util io 0x61 1  
>>> chipsec_util io 0x430 byte 0x0
```

chipsec.utilcmd.iommu_cmd module

Command-line utility providing access to IOMMU engines

```
class IOMMUCommand (argv, cs=None)
```

```
Bases: chipsec.command.BaseCommand
```

```
>>> chipsec_util iommu list  
>>> chipsec_util iommu config [iommu_engine]  
>>> chipsec_util iommu status [iommu_engine]  
>>> chipsec_util iommu enable|disable <iommu_engine>  
>>> chipsec_util iommu pt
```

Examples:

```
>>> chipsec_util iommu list  
>>> chipsec_util iommu config VTD  
>>> chipsec_util iommu status GFXVTD  
>>> chipsec_util iommu enable VTD  
>>> chipsec_util iommu pt
```

chipsec.utilcmd.mem_cmd module

The mem command provides direct access to read and write physical memory.



class MemCommand (argv, cs=None)

Bases: **chipsec.command.BaseCommand**

```
>>> chipsec_util mem <op> <physical_address> <length> [value|buffer_file]
>>>
>>> <physical_address> : 64-bit physical address
>>> <op>                : read|readval|write|writeval|allocate|pagedump
>>> <length>            : byte|word|dword or length of the buffer from <buffer_file>
>>> <value>             : byte, word or dword value to be written to memory at <physical_address>
>>> <buffer_file>      : file with the contents to be written to memory at <physical_address>
```

Examples:

```
>>> chipsec_util mem <op> <physical_address> <length> [value|file]
>>> chipsec_util mem readval 0xFED40000 dword
>>> chipsec_util mem read 0x41E 0x20 buffer.bin
>>> chipsec_util mem writeval 0xA0000 dword 0x9090CCCC
>>> chipsec_util mem write 0x10000000 0x1000 buffer.bin
>>> chipsec_util mem write 0x10000000 0x10 00102030405060708090A0B0C0D0E0F
>>> chipsec_util mem allocate 0x1000
>>> chipsec_util mem pagedump 0xFED00000 0x100000
```

chipsec.utilcmd.mmcfg_cmd module

The mmcfg command allows direct access to memory mapped config space.

class MMCFGCommand (argv, cs=None)

Bases: **chipsec.command.BaseCommand**

```
>>> chipsec_util mmcfg <bus> <device> <function> <offset> <width> [value]
```

Examples:

```
>>> chipsec_util mmcfg 0 0 0 0x88 4
>>> chipsec_util mmcfg 0 0 0 0x88 byte 0x1A
>>> chipsec_util mmcfg 0 0x1F 0 0xDC 1 0x1
>>> chipsec_util mmcfg 0 0 0 0x98 dword 0x004E0040
```

chipsec.utilcmd.mmio_cmd module

class MMIOCommand (argv, cs=None)

Bases: **chipsec.command.BaseCommand**

```
>>> chipsec_util mmio list
>>> chipsec_util mmio dump <MMIO_BAR_name>
>>> chipsec_util mmio read <MMIO_BAR_name> <offset> <width>
>>> chipsec_util mmio write <MMIO_BAR_name> <offset> <width> <value>
```

Examples:

```
>>> chipsec_util mmio list
>>> chipsec_util mmio dump MCHBAR
>>> chipsec_util mmio read SPIBAR 0x74 0x4
>>> chipsec_util mmio write SPIBAR 0x74 0x4 0xFFFF0000
```

chipsec.utilcmd.msgbus_cmd module

class MsgBusCommand (argv, cs=None)

Bases: **chipsec.command.BaseCommand**



```
>>> chipsec_util msgbus read <port> <register>
>>> chipsec_util msgbus write <port> <register> <value>
>>> chipsec_util msgbus message <port> <register> <opcode> [value]
>>>
>>> <port> : message bus port of the target unit
>>> <register>: message bus register/offset in the target unit port
>>> <value> : value to be written to the message bus register/offset
>>> <opcode> : opcode of the message on the message bus
```

Examples:

```
>>> chipsec_util msgbus read 0x3 0x2E
>>> chipsec_util msgbus write 0x3 0x27 0xE0000001
>>> chipsec_util msgbus message 0x3 0x2E 0x10
>>> chipsec_util msgbus message 0x3 0x2E 0x11 0x0
```

chipsec.utilcmd.msr_cmd module

The msr command allows direct access to read and write MSRs.

class **MSRCommand** (argv, cs=None)

Bases: **chipsec.command.BaseCommand**

```
>>> chipsec_util msr <msr> [eax] [edx] [cpu_id]
```

Examples:

```
>>> chipsec_util msr 0x3A
>>> chipsec_util msr 0x8B 0x0 0x0 0
```

chipsec.utilcmd.pci_cmd module

The pci command can enumerate PCI/PCIe devices, enumerate expansion ROMs and allow direct access to PCI configuration registers via bus/device/function.

class **PCICCommand** (argv, cs=None)

Bases: **chipsec.command.BaseCommand**

```
>>> chipsec_util pci enumerate
>>> chipsec_util pci <bus> <device> <function> <offset> [width] [value]
>>> chipsec_util pci dump [<bus> <device> <function>]
>>> chipsec_util pci xrom [<bus> <device> <function>] [xrom_address]
```

Examples:

```
>>> chipsec_util pci enumerate
>>> chipsec_util pci 0 0 0 0x00
>>> chipsec_util pci 0 0 0 0x88 byte 0x1A
>>> chipsec_util pci 0 0x1F 0 0xDC 1 0x1
>>> chipsec_util pci 0 0 0 0x98 dword 0x004E0040
>>> chipsec_util pci dump
>>> chipsec_util pci dump 0 0 0
>>> chipsec_util pci xrom
>>> chipsec_util pci xrom 3 0 0 0xFEDF0000
```

chipsec.utilcmd.smbus_cmd module

class **SMBusCommand** (argv, cs=None)

Bases: **chipsec.command.BaseCommand**



```
>>> chipsec_util smbus read <device_addr> <start_offset> [size]
>>> chipsec_util smbus write <device_addr> <offset> <byte_val>
```

Examples:

```
>>> chipsec_util smbus read 0xA0 0x0 0x100
```

chipsec.utilcmd.spd_cmd module

class **SPDCommand** (argv, cs=None)

Bases: **chipsec.command.BaseCommand**

```
>>> chipsec_util spd detect
>>> chipsec_util spd dump [device_addr]
>>> chipsec_util spd read <device_addr> <offset>
>>> chipsec_util spd write <device_addr> <offset> <byte_val>
```

Examples:

```
>>> chipsec_util spd detect
>>> chipsec_util spd dump DIMM0
>>> chipsec_util spd read 0xA0 0x0
>>> chipsec_util spd write 0xA0 0x0 0xAA
```

chipsec.utilcmd.spi_cmd module

CHIPSEC includes functionality for reading and writing the SPI flash. When an image file is created from reading the SPI flash, this image can be parsed to reveal sections, files, variables, etc.

Warning

Particular care must be taken when using the spi write and spi erase functions. These could make your system unbootable.

A basic forensic operation might be to dump the entire SPI flash to a file. This is accomplished as follows:

```
# python chipsec_util.py spi dump rom.bin
```

The file rom.bin will contain the full binary of the SPI flash. It can then be parsed using the decode util command.

class **SPICCommand** (argv, cs=None)

Bases: **chipsec.command.BaseCommand**

```
>>> chipsec_util spi info|dump|read|write|erase|disable-wp [flash_address] [length] [file]
```

Examples:

```
>>> chipsec_util spi info
>>> chipsec_util spi dump rom.bin
>>> chipsec_util spi read 0x700000 0x100000 bios.bin
>>> chipsec_util spi write 0x0 flash_descriptor.bin
>>> chipsec_util spi disable-wp
```

chipsec.utilcmd.spidesc_cmd module



```
class SPIDescCommand (argv, cs=None)
Bases: chipsec.command.BaseCommand
```

```
>>> chipsec_util spidesc [rom]
```

Examples:

```
>>> chipsec_util spidesc spi.bin
```

chipsec.utilcmd.unicode_cmd module

```
class UCodeCommand (argv, cs=None)
Bases: chipsec.command.BaseCommand
```

```
>>> chipsec_util unicode id|load|decode [ucode_update_file (in .PDB or .BIN format)] [cpu_id]
```

Examples:

```
>>> chipsec_util unicode id
>>> chipsec_util unicode load ucode.bin 0
>>> chipsec_util unicode decode ucode.pdb
```

chipsec.utilcmd.uefi_cmd module

The uefi command provides access to UEFI variables, both on the live system and in a SPI flash image file.

```
class UEFICCommand (argv, cs=None)
Bases: chipsec.command.BaseCommand
```

```
>>> chipsec_util uefi types
>>> chipsec_util uefi var-list
>>> chipsec_util uefi var-find <name>|<GUID>
>>> chipsec_util uefi var-read|var-write|var-delete <name> <GUID> <efi_variable_file>
>>> chipsec_util uefi decode <rom_file> [fwtype]
>>> chipsec_util uefi nvram[-auth] <rom_file> [fwtype]
>>> chipsec_util uefi keys <keyvar_file>
>>> chipsec_util uefi tables
>>> chipsec_util uefi s3bootscript [script_address]
>>> chipsec_util uefi assemble <GUID> freeform none|lzma|tiano <raw_file> <uefi_file>
>>> chipsec_util uefi insert_before|insert_after|replace|remove <GUID> <rom> <new_rom> <uefi_file>
```

Examples:

```
>>> chipsec_util uefi types
>>> chipsec_util uefi var-list
>>> chipsec_util uefi var-find PK
>>> chipsec_util uefi var-read db D719B2CB-3D3A-4596-A3BC-DAD00E67656F db.bin
>>> chipsec_util uefi var-write db D719B2CB-3D3A-4596-A3BC-DAD00E67656F db.bin
>>> chipsec_util uefi var-delete db D719B2CB-3D3A-4596-A3BC-DAD00E67656F
>>> chipsec_util uefi decode uefi.rom
>>> chipsec_util uefi nvram uefi.rom vss_auth
>>> chipsec_util uefi keys db.bin
>>> chipsec_util uefi tables
>>> chipsec_util uefi s3bootscript
>>> chipsec_util uefi assemble AAAAAAAA-BBBB-CCCC-DDDD-EEEEEEEEEEEE freeform lzma uefi.raw mydriver.efi
>>> chipsec_util uefi replace AAAAAAAA-BBBB-CCCC-DDDD-EEEEEEEEEEEE bios.bin new_bios.bin mydriver.efi
```

chipsec.utilcmd.vmm_cmd module

```
class VMMCommand (argv, cs=None)
```



Bases: `chipsec.command.BaseCommand`

```
>>> chipsec_util vmm hypercall <rax> <rbx> <rcx> <rdx> <rdi> <rsi> [r8] [r9] [r10] [r11]
>>> chipsec_util vmm hypercall <eax> <ebx> <ecx> <edx> <edi> <esi>
>>> chipsec_util vmm pt|ept <ept_pointer>
>>> chipsec_util vmm virtio [<bus>:<device>.<function>]
```

Examples:

```
>>> chipsec_util vmm hypercall 32 0 0 0 0 0
>>> chipsec_util vmm pt 0x524B01E
>>> chipsec_util vmm virtio
>>> chipsec_util vmm virtio 0:6.0
```

Auxiliary components

<code>setup.py</code>	setup script to install CHIPSEC as a package
-----------------------	--

Executable build scripts

<CHIPSEC_ROOT>/scripts/build_exe_*.py make files to build Windows executables

CHIPSEC Modules

Introduction

<code>chipsec/modules/</code>	modules including tests or tools (that's where most of the chipsec functionality is)
<code>chipsec/modules/common/</code>	modules common to all platforms
<code>chipsec/modules/<platform></code>	modules specific to <platform>
<code>chipsec/modules/tools/</code>	security tools based on CHIPSEC framework (fuzzers, etc.)

A CHIPSEC module is just a python class that inherits from `BaseModule` and implements `is_supported` and `run`. Modules are stored under the chipsec installation directory in a subdirectory "modules". The "modules" directory contains one subdirectory for each chipset that chipsec supports. There is also a directory for common modules that should apply to every platform.

Internally the chipsec application uses the concept of a module name, which is a string of the form: `common.bios_wp`. This means module `common.bios_wp` is a python script called `bios_wp.py` that is stored at `<ROOT_DIR>\chipsec\modules\common\`.

Modules can be mapped to one or more security vulnerabilities being checked. Consult the documentation for an individual module for more information.



Modules Description

chipsec.modules.common.secureboot.variables module

UEFI 2.4 spec Section 28

Verify that all Secure Boot key/whitelist/blacklist UEFI variables are authenticated (BS+RT+AT) and protected from unauthorized modification.

Use '-a modify' option for the module to also try to write/corrupt the variables.

chipsec.modules.common.uefi.access_ufispec module

Checks protection of UEFI variables defined in the UEFI spec to have certain permissions.

Returns failure if variable attributes are not as defined in table 11 "Global Variables" of the UEFI spec.

chipsec.modules.common.uefi.s3bootscript module

Checks protections of the S3 resume boot-script implemented by the UEFI based firmware

References:

[VU#976132 UEFI implementations do not properly secure the EFI S3 Resume Boot Path boot script](#)

[Technical Details of the S3 Resume Boot Script Vulnerability](#) by Intel Security's Advanced Threat Research team.

[Attacks on UEFI Security](#) by Rafal Wojtczuk and Corey Kallenberg.

[Attacking UEFI Boot Script](#) by Rafal Wojtczuk and Corey Kallenberg.

[Exploiting UEFI boot script table vulnerability](#) by Dmytro Oleksiuk.

Usage:

```
>>> chipsec_main.py -m common.uefi.s3bootscript [-a <script_address>]
```

Examples:

```
>>> chipsec_main.py -m common.uefi.s3bootscript
>>> chipsec_main.py -m common.uefi.s3bootscript -a 0x00000000BDE10000
```

chipsec.modules.common.bios_kbrd_buffer module

[DEFCON 16: Bypassing Pre-boot Authentication Passwords by Instrumenting the BIOS Keyboard Buffer](#) by Jonathan Brossard

Checks for BIOS/HDD password exposure through BIOS keyboard buffer.

Checks for exposure of pre-boot passwords (BIOS/HDD/pre-bot authentication SW) in the BIOS keyboard buffer.

chipsec.modules.common.bios_smi module

The module checks that SMI events configuration is locked down - Global SMI Enable/SMI Lock - TCO SMI Enable/TCO Lock



Modules Description

References:

[Setup for Failure: Defeating SecureBoot](#) by Corey Kallenberg, Xeno Kovah, John Butterworth, Sam Cornwell

[Summary of Attacks Against BIOS and Secure Boot](https://www.defcon.org/images/defcon-22/dc-22-presentations/Bulygin-Bazhaniul-Furtak-Loucaides/DEFCON-22-Bulygin-Bazhaniul-Furtak-Loucaides-Summary-of-attacks-against-BIOS-UPDATED.pdf) (<https://www.defcon.org/images/defcon-22/dc-22-presentations/Bulygin-Bazhaniul-Furtak-Loucaides/DEFCON-22-Bulygin-Bazhaniul-Furtak-Loucaides-Summary-of-attacks-against-BIOS-UPDATED.pdf>)

chipsec.modules.common.bios_ts module

Checks for BIOS Interface Lock including Top Swap Mode

[BIOS Boot Hijacking and VMware Vulnerabilities Digging](#) by Bing Sun

chipsec.modules.common.bios_wp module

The BIOS region in flash can be protected either using SMM-based protection or using configuration in the SPI controller. However, the SPI controller configuration is set once and locked, which would prevent writes later.

This module does check both mechanisms. In order to pass this test using SPI controller configuration, the SPI Protected Range registers (PRO-4) will need to cover the entire BIOS region. Often, if this configuration is used at all, it is used only to protect part of the BIOS region (usually the boot block). If other important data (eg. NVRAM) is not protected, however, some vulnerabilities may be possible.

[A Tale of One Software Bypass of Windows 8 Secure Boot](#) described just such an attack. In a system where certain BIOS data was not protected, malware may be able to write to the Platform Key stored on the flash, thereby disabling secure boot.

SMM based write protection is controlled from the BIOS Control Register. When the BIOS Write Protect Disable bit is set (sometimes called BIOSWE or BIOS Write Enable), then writes are allowed. When cleared, it can also be locked with the BIOS Lock Enable (BLE) bit. When locked, attempts to change the WPD bit will result in generation of an SMI. This way, the SMI handler can decide whether to perform the write.

As demonstrated in the [Speed Racer](#) issue, a race condition may exist between the outstanding write and processing of the SMI that is generated. For this reason, the EISS bit (sometimes called SMM_BWP or SMM BIOS Write Protection) must be set to ensure that only SMM can write to the SPI flash.

This module `common.bios_wp` will fail if SMM-based protection is not correctly configured and SPI protected ranges (PR registers) do not protect the entire BIOS region.

chipsec.modules.common.ia32cfg module

Tests that IA-32/IA-64 architectural features are configured and locked, including IA32 Model Specific Registers (MSRs)

Reference: Intel Software Developer's Manual

chipsec.modules.common.rtclock module

Checks for RTC memory locks. Since we do not know what RTC memory will be used for on a specific platform, we return WARNING (rather than FAILED) if the memory is not locked.



chipsec.modules.common.smm module

In 2006, [Security Issues Related to Pentium System Management Mode](#) outlined a configuration issue where compatibility SMRAM was not locked on some platforms. This means that ring 0 software was able to modify System Management Mode (SMM) code and data that should have been protected.

In Compatibility SMRAM (CSEG), access to memory is defined by the SMRAMC register. When SMRAMC[D_LCK] is not set by the BIOS, SMRAM can be accessed even when the CPU is not in SMM. Such attacks were also described in [Using CPU SMM to Circumvent OS Security Functions](#) and [Using SMM for Other Purposes](#).

This CHIPSEC module simply reads SMRAMC and checks that D_LCK is set.

chipsec.modules.common.smrr module

Researchers demonstrated a way to use CPU cache to effectively change values in SMRAM in [Attacking SMM Memory via Intel CPU Cache Poisoning](#) and [Getting into the SMRAM: SMM Reloaded](#). If ring 0 software can make SMRAM cacheable and then populate cache lines at SMBASE with exploit code, then when an SMI is triggered, the CPU could execute the exploit code from cache. System Management Mode Range Registers (SMRRs) force non-cacheable behavior and block access to SMRAM when the CPU is not in SMM. These registers need to be enabled/configured by the BIOS.

This module checks to see that SMRRs are enabled and configured.

chipsec.modules.common.spi_desc module

The SPI Flash Descriptor indicates read/write permissions for devices to access regions of the flash memory. This module simply reads the Flash Descriptor and checks that software cannot modify the Flash Descriptor itself. If software can write to the Flash Descriptor, then software could bypass any protection defined by it. While often used for debugging, this should not be the case on production systems.

This module checks that software cannot write to the flash descriptor.

chipsec.modules.common.spi_fdopss module

Checks for SPI Controller Flash Descriptor Security Override Pin Strap (FDOPSS). On some systems, this may be routed to a jumper on the motherboard.

chipsec.modules.common.spi_lock module

The configuration of the SPI controller, including protected ranges (PR0-PR4), is locked by HSFS[FLOCKDN] until reset. If not locked, the controller configuration may be bypassed by reprogramming these registers.

This vulnerability (not setting FLOCKDN) is also checked by other tools, including [flashrom](#) and Copernicus by MITRE (ref: [Copernicus: Question Your Assumptions about BIOS Security](#) <http://www.mitre.org/capabilities/cybersecurity/overview/cybersecurity-blog/copernicus-question-your-assumptions-about>).

This module checks that the SPI Flash Controller configuration is locked.

chipsec.modules.tools.cpu.sinkhole module

This module checks if CPU is affected by 'The SMM memory sinkhole' vulnerability by Christopher Domas



Modules Description

NOTE: The system may hang when running this test. In that case, the mitigation to this issue is likely working but we may not be handling the exception generated.

References:

The Memory Sinkhole by Christopher Domas: <https://www.blackhat.com/docs/us-15/materials/us-15-Domas-The-Memory-Sinkhole-Unleashing-An-x86-Design-Flaw-Allowing-Universal-Privilege-Escalation.pdf> (presentation) and <https://www.blackhat.com/docs/us-15/materials/us-15-Domas-The-Memory-Sinkhole-Unleashing-An-x86-Design-Flaw-Allowing-Universal-Privilege-Escalation-wp.pdf> (whitepaper).

chipsec.modules.tools.secureboot.te module

Tool to test for 'TE Header' vulnerability in Secure Boot implementations as described in [All Your Boot Are Belong To Us](#)

Usage:

```
chipsec_main.py -m tools.secureboot.te [-a <mode>,<cfg_file>,<efi_file>]
```

- <mode>
 - `generate_te` (default) convert PE EFI binary <efi_file> to TE binary
 - `replace_bootloader` replace bootloader files listed in <cfg_file> on ESP with modified <efi_file>
 - `restore_bootloader` restore original bootloader files from .bak files
- <cfg_file> path to config file listing paths to bootloader files to replace
- <efi_file> path to EFI binary to convert to TE binary. If no file path is provided, the tool will look for Shell.efi

Examples:

Convert Shell.efi PE/COFF EFI executable to TE executable:

```
chipsec_main.py -m tools.secureboot.te -a generate_te,Shell.efi
```

Replace bootloaders listed in te.cfg file with TE version of Shell.efi executable:

```
chipsec_main.py -m tools.secureboot.te -a replace_bootloader,te.cfg,Shell.efi
```

Restore bootloaders listed in te.cfg file:

```
chipsec_main.py -m tools.secureboot.te -a restore_bootloader,te.cfg
```

chipsec.modules.tools.smm.smm_ptr module

CanSecWest 2015 [A New Class of Vulnerability in SMI Handlers of BIOS/UEFI Firmware](#)

A tool to test SMI handlers for pointer validation vulnerabilities

Usage: `chipsec_main -m tools.smm.smm_ptr -l log.txt \`
`[-a <mode>,<config_file>|<smic_start:smic_end>,<size>,<address>]`

- mode: SMI fuzzing mode
 - `config` = use SMI configuration file <config_file>
 - `fuzz` = fuzz all SMI handlers with code in the range <smic_start:smic_end>
 - `fuzzmore` = fuzz mode + pass 2nd-order pointers within buffer to SMI handlers
- size: size of the memory buffer (in Hex)



Modules Description

- `address`: physical address of memory buffer to pass in GP regs to SMI handlers (in Hex)
- `smram` = option passes address of SMRAM base (system may hang in this mode!)

In `config` mode, SMI configuration file should have the following format

```
SMI_code=<SMI code> or *
SMI_data=<SMI data> or *
RAX=<value of RAX> or * or PTR or VAL
RBX=<value of RBX> or * or PTR or VAL
RCX=<value of RCX> or * or PTR or VAL
RDX=<value of RDX> or * or PTR or VAL
RSI=<value of RSI> or * or PTR or VAL
RDI=<value of RDI> or * or PTR or VAL
[PTR_OFFSET=<offset to pointer in the buffer>]
[SIG=<signature>]
[SIG_OFFSET=<offset to signature in the buffer>]
[Name=<SMI name>]
[Desc=<SMI description>]
```

Where

- `[]`: optional line
- `*`: Don't Care (the module will replace `*` with `0x0`)
- `PTR`: Physical address SMI handler will write to (the module will replace `PTR` with physical address provided as a command-line argument)
- `VAL`: Value SMI handler will write to `PTR` address (the module will replace `VAL` with hardcoded `_FILL_VALUE_xx`)

chipsec.modules.tools.uefi.blacklist module

This module checks current contents of UEFI firmware ROM or specified firmware image for black-listed EFI binaries which can be EFI firmware volumes, EFI executable binaries (PEI modules, DXE drivers..) or EFI sections. The module can find EFI binaries by their UI names, EFI GUIDs, MD5/SHA-1/SHA-256 hashes or contents matching specified regular expressions.

Important! This module can only detect what it knows about from its config file. If a bad or vulnerable binary is not detected then its 'signature' needs to be added to the config.

Usage:

```
chipsec_main.py -i -m tools.uefi.blacklist [-a <fw_image>,<blacklist>]
```

- `fw_image` Full file path to UEFI firmware image. If not specified, the module will dump firmware image directly from ROM
- `blacklist` JSON file with configuration of black-listed EFI binaries (default = `blacklist.json`). Config file should be located in the same directory as this module

Examples:

```
>>> chipsec_main.py -m tools.uefi.blacklist
```

Dumps UEFI firmware image from flash memory device, decodes it and checks for black-listed EFI modules defined in the default config `blacklist.json`

```
>>> chipsec_main.py -i --no_driver -m tools.uefi.blacklist -a uefi.rom,blacklist.json
```

Decodes `uefi.rom` binary with UEFI firmware image and checks for black-listed EFI modules defined in `blacklist.json` config

Note: `-i` and `--no_driver` arguments can be used in this case because the test does not depend on the platform and no kernel driver is required when firmware image is specified



chipsec.modules.tools.uefi.s3script_modify module

This module will attempt to modify the S3 Boot Script on the platform. Doing this could cause the platform to malfunction. Use with care!

Usage:

Replacing existing opcode:

```
chipsec_main.py -m tools.uefi.s3script_modify \  
-a replace_op,<reg_opcode>,<address>,<value>  
  
    <reg_opcode> = pci_wr|mmio_wr|io_wr|pci_rw|mmio_rw|io_rw  
chipsec_main.py -m tools.uefi.s3script_modify -a replace_op,mem[,<address>,<value>]  
chipsec_main.py -m tools.uefi.s3script_modify -a replace_op,dispatch  
chipsec_main.py -m tools.uefi.s3script_modify -a replace_op,dispatch_ep
```

Adding new opcode:

```
chipsec_main.py -m tools.uefi.s3script_modify \  
-a add_op,<reg_opcode>,<address>,<value>,<width>  
  
    <reg_opcode> = pci_wr|mmio_wr|io_wr  
chipsec_main.py -m tools.uefi.s3script_modify -a add_op,dispatch[,<entrypoint>]
```

Examples:

```
>>> chipsec_main.py -m tools.uefi.s3script_modify -a replace_op,<reg_opcode>,<address>,<value>  
>>>    <reg_opcode> = pci_wr|mmio_wr|io_wr|pci_rw|mmio_rw|io_rw
```

The option will look for a script opcode that writes to PCI config, MMIO or I/O registers and modify the opcode to write the given value to the register with the given address.

After executing this, if the system is vulnerable to boot script modification, the hardware configuration will have changed according to given <reg_opcode>.

```
>>> chipsec_main.py -m tools.uefi.s3script_modify -a replace_op,mem
```

The option will look for a script opcode that writes to memory and modify the opcode to write the given value to the given address.

By default this test will allocate memory and write write 0xB007B007 that location.

After executing this, if the system is vulnerable to boot script modification, you should find the given value in the allocated memory location.

```
>>> chipsec_main.py -m tools.uefi.s3script_modify -a replace_op,dispatch
```

The option will look for a dispatch opcode in the script and modify the opcode to point to a different entry point. The new entry point will contain a HLT instruction.

After executing this, if the system is vulnerable to boot script modification, the system should hang on resume from S3.

```
>>> chipsec_main.py -m tools.uefi.s3script_modify -a replace_op,dispatch_ep
```

The option will look for a dispatch opcode in the script and will modify memory at the entry point for that opcode. The modified instructions will contain a HLT instruction.

After executing this, if the system is vulnerable to dispatch opcode entry point modification, the system should hang on resume from S3.

```
>>> chipsec_main.py -m tools.uefi.s3script_modify -a add_op,<reg_opcode>,<address>,<value>,<width>  
>>>    <reg_opcode> = pci_wr|mmio_wr|io_wr
```

The option will add a new opcode which writes to PCI config, MMIO or I/O registers with specified values.

```
>>> chipsec_main.py -m tools.uefi.s3script_modify -a add_op,dispatch
```



Modules Description

The option will add a new DISPATCH opcode to the script with entry point to either existing or newly allocated memory.

chipsec.modules.tools.vmm.hv.define module

Hyper-V specific defines

chipsec.modules.tools.vmm.hv.hypercall module

Hyper-V specific hypercall functionality

getrandbits (k) → x. Generates a long int with k random bits.

chipsec.modules.tools.vmm.hv.hypercallfuzz module

Hyper-V hypercall fuzzer

Usage:

```
chipsec_main.py -i -m tools.vmm.hv.hypercall -a <mode>[,<vector>,<iterations>] -l log.txt
```

- **mode** fuzzing mode
 - = `status-fuzzing` finding parameters with hypercall success status
 - = `params-info` shows input parameters valid ranges
 - = `params-fuzzing` parameters fuzzing based on their valid ranges
 - = `custom-fuzzing` fuzzing of known hypercalls
- **vector** hypercall vector
- **iterations** number of hypercall iterations

Note: the fuzzer is incompatible with native VMBus driver (`vmbus.sys`). To use it, remove `vmbus.sys`

getrandbits (k) → x. Generates a long int with k random bits.

chipsec.modules.tools.vmm.hv.synth_dev module

Hyper-V VMBus synthetic device generic fuzzer

Usage:

Print channel offers:

```
chipsec_main.py -i -m tools.vmm.hv.synth_dev -a info
```

Fuzzing device with specified relid:

```
chipsec_main.py -i -m tools.vmm.hv.synth_dev -a fuzz,<relid> -l log.txt
```

Note: the fuzzer is incompatible with native VMBus driver (`vmbus.sys`). To use it, remove `vmbus.sys`

getrandbits (k) → x. Generates a long int with k random bits.



chipsec.modules.tools.vmm.hv.synth_kbd module

Hyper-V VMBus synthetic keyboard fuzzer. Fuzzes inbound ring buffer in VMBus virtual keyboard device.

Usage:

```
chipsec_main.py -i -m tools.vmm.hv.synth_kbd -a fuzz -l log.txt
```

Note: the fuzzer is incompatible with native VMBus driver (`vmbus.sys`). To use it, remove `vmbus.sys`

`getrandbits (k) → x`. Generates a long int with k random bits.

chipsec.modules.tools.vmm.hv.vmbus module

Hyper-V VMBus functionality

`getrandbits (k) → x`. Generates a long int with k random bits.

chipsec.modules.tools.vmm.hv.vmbusfuzz module

Hyper-V VMBus generic fuzzer

Usage:

```
chipsec_main.py -i -m tools.vmm.hv.vmbusfuzz -a fuzz,<parameters> -l log.txt
```

Parameters:

- `all` fuzzing all bytes
- `hv` fuzzing HyperV message header
- `vmbus` fuzzing HyperV message body / VMBUS message
- `<pos>, <size>` fuzzing number of bytes at specific position

Note: the fuzzer is incompatible with native VMBus driver (`vmbus.sys`). To use it, remove `vmbus.sys`

`getrandbits (k) → x`. Generates a long int with k random bits.

chipsec.modules.tools.vmm.vbox.vbox_crash_apicbase module

PoC test for Host OS Crash when writing to IA32_APIC_BASE MSR (Oracle VirtualBox CVE-2015-0377)

<http://www.oracle.com/technetwork/topics/security/cpujan2015-1972971.html>

Usage:

```
chipsec_main.py -i -m tools.vmm.vbox_crash_apicbase
```

chipsec.modules.tools.vmm.xen.define module

Xen specific defines

chipsec.modules.tools.vmm.xen.hypercall module

Xen specific hypercall functionality



getrandbits (k) → x. Generates a long int with k random bits.

chipsec.modules.tools.vmm.xen.hypercallfuzz module

Xen hypercall fuzzer

Usage:

```
chipsec_main.py -i -m tools.vmm.xen.hypercallfuzz \  
-a <mode>[,<vector>,<iterations>] -l log.txt
```

- mode fuzzing mode
 - = help prints this help
 - = info hypervisor information
 - = fuzzing fuzzing specified hypercall
 - = fuzzing-all fuzzing all hypercalls
 - = fuzzing-all-randomly fuzzing random hypercalls
- vector code or name of a hypercall to be fuzzed (use info)
- iterations number of fuzzing iterations

Examples:

```
chipsec_main.py -i -m tools.vmm.xen.hypercallfuzz -a sched_op,10 -l log.txt  
chipsec_main.py -i -m tools.vmm.xen.hypercallfuzz -a xen_version,50 -l log.txt  
chipsec_main.py -i -m tools.vmm.xen.hypercallfuzz -a set_timer_op,10,0x10000000 -l log.txt
```

getrandbits (k) → x. Generates a long int with k random bits.

chipsec.modules.tools.vmm.xen.xsa188 module

Proof-of-concept module for Xen XSA-188 (<https://xenbits.xen.org/xsa/advisory-188.html>) CVE-2016-7154: "use after free in FIFO event channel code" Discovered by Mikhail Gorobets

This module triggers host crash on vulnerable Xen 4.4

Usage:

```
chipsec_main.py -m tools.vmm.xen.xsa188
```

chipsec.modules.tools.vmm.common module

Common functionality for VMM related modules/tools

getrandbits (k) → x. Generates a long int with k random bits.

chipsec.modules.tools.vmm.cpuid_fuzz module

Simple CPUID VMM emulation fuzzer

Usage:

```
chipsec_main.py -i -m tools.vmm.cpuid_fuzz -l log.txt
```



chipsec.modules.tools.vmm.hypercallfuzz module

Pretty simple VMM hypercall fuzzer

Usage:

```
chipsec_main.py -i -m tools.vmm.hypercallfuzz \  
[-a <mode>,<vector_reg>,<maxval>,<iterations>] -l log.txt
```

- mode **hypercall fuzzing mode**
 - = exhaustive fuzz all arguments exhaustively in range [0:<maxval>] (default)
 - = random send random values in all registers in range [0:<maxval>]
- vector_reg hypercall vector register
- maxval maximum value of each register
- iterations number of iterations in random mode

chipsec.modules.tools.vmm.iofuzz module

Simple port I/O VMM emulation fuzzer

Usage:

```
chipsec_main.py -i -m tools.vmm.iofuzz [-a <mode>,<count>,<iterations>] -l log.txt
```

chipsec.modules.tools.vmm.msr_fuzz module

Simple CPU Module Specific Register (MSR) VMM emulation fuzzer

Usage:

```
chipsec_main.py -i -m tools.vmm.msr_fuzz [-a random] -l log.txt
```

chipsec.modules.tools.vmm.pcie_fuzz module

Simple PCIe device Memory-Mapped I/O (MMIO) and I/O ranges VMM emulation fuzzer

Usage:

```
chipsec_main.py -i -m tools.vmm.pcie_fuzz -l log.txt
```

chipsec.modules.tools.vmm.pcie_overlap_fuzz module

PCIe device Memory-Mapped I/O (MMIO) ranges VMM emulation fuzzer which first overlaps MMIO BARs of all available PCIe devices then fuzzes them by writing garbage if corresponding option is enabled

Usage:

```
chipsec_main.py -i -m tools.vmm.pcie_overlap_fuzz -l log.txt
```

chipsec.modules.tools.vmm.venom module



Modules Description

QEMU VENOM vulnerability DoS PoC test Module is based on PoC by Marcus Meissner (<https://marc.info/?l=oss-security&m=143155206320935&w=2>)

Usage:

```
chipsec_main.py -i -m tools.vmm.venom
```

chipsec.modules.memconfig module

This module verifies memory map secure configuration, i.e. that memory map registers are correctly configured and locked down.

chipsec.modules.remap module

Preventing & Detecting Xen Hypervisor Subversions by Joanna Rutkowska & Rafal Wojtczuk

Check Memory Remapping Configuration

chipsec.modules.smm_dma module

Just like SMRAM needs to be protected from software executing on the CPU, it also needs to be protected from devices that have direct access to DRAM (DMA). Protection from DMA is configured through proper programming of SMRAM memory range. If BIOS does not correctly configure and lock the configuration, then malware could reprogram configuration and open SMRAM area to DMA access, allowing manipulation of memory that should have been protected.

DMA attacks were discussed in [Programmed I/O accesses: a threat to Virtual Machine Monitors?](#) and [System Management Mode Design and Security Issues](#). This is also discussed in *Summary of Attack against BIOS and Secure Boot* <https://www.defcon.org/images/defcon-22/dc-22-presentations/Bulygin-Bazhaniul-Furtak-Loucaides/DEFCON-22-Bulygin-Bazhaniul-Furtak-Loucaides-Summary-of-attacks-against-BIOS-UPDATED.pdf>

This module examines the configuration and locking of SMRAM range configuration protecting from DMA attacks. If it fails, then DMA protection may not be securely configured to protect SMRAM.